

Retouch Crayons



For filling and masking superficial scratches on finished wooden surfaces.

Purpose

Liberon Retouch Crayons can be used to fill scratches, nail holes, worm holes etc. in furniture and other woodwork. Easy to use, they are available in a wide range of colours.

Performance

- For filling and masking superficial scratches on finished wood
- Expand and contract with the wood
- Do not shrink or drop out
- Easy rub on and buff off application
- Wide range of colours available

How to Use

Application

Rub the crayon across the scratch until it is filled, allow to harden then buff off the excess with a cotton cloth.

Retouch crayons may be blended together to create different shades.

Important

Always test product on a spare surface or inconspicuous area for colour, compatibility and end result.

Colours: Mahogany, Pine, Oak, Mixed, Kitchen and Walnut.

Pack Size: 3 pack blister

