

Retouch Cream



Soft wax for restoring colour and disguising dents and chips.

Purpose

Liberon Retouch Cream is a soft creamy wax for filling mitre joints and pin holes on frames or furniture during restoration. It is also used to colour scratches and small defects.

Performance

- A soft wax for rubbing into damaged areas
- Restores colour and disguises dents and chips
- Ideal for filling mitre joints and pin holes on frames or furniture
- Dries hard
- All colours are intermixable

How to Use

Preparation

Ensure surface is clean, dry and free from dust.

Application

Apply to the damaged surface with a cloth. Gently remove any excess with a cloth. Allow to dry for a minimum of 20 minutes, longer if possible, then buff lightly with a lint-free cotton cloth.

Tools can be cleaned with white spirit. If the product dries out it can be re-activated by gently warming and adding white spirit.

Colours: White, Black, Mahogany, Light Oak

Pack Size: 30ml

